

# 2008 JackRabbit® Application Guide

**\*\* BOTH A CANISTER PART AND RAIL PART MUST BE ORDERED TO MAKE A COMPLETE UNIT \*\***

YEAR	MODEL	BED LENGTH	BOX	CANISTER PART #	RAIL PART #
<b>CHEVY/ GMC</b>					
94-03	S-10/Sonoma	6'	SB	TR2001	TR5001
94-03	S-10/Sonoma	7' 4"	LB	TR2002	TR5002
04-08	Colorado/Canyon	6'	SB	TR2006	TR5046
04-08	Colorado/Canyon Crew Cab (*1)	5'	XSB	TR2034	TR5053
04-08	Silverado 1500 Crew Cab	5' 8"	XSB	TR2032	TR5050
04-08	Silverado HD 2500/3500 Dual Rear Wheel	8'	LB	TR2055	TR5069
88-08	C/K/Silverado, Heavy Duty ^	6' 6"	SB	TR2003	TR5003
88-08	C/K/Silverado, Heavy Duty	8'	LB	TR2004	TR5004
67-87	C/K Full-size***	6' 5"	SB	TR2013	TR5029
67-87	C/K Full-size***	8'	LB	TR2012	TR5004
88-06	Stepside**	6' 6"	SB	TR2025	TR5076

## WITH OPTIONAL CARGO MANAGEMENT SYSTEM TRACK

07-08	Silverado 1500 Crew Cab w/ CMS Track (*2)	5' 8"	XSB	TR2056	TR5070
07-08	Silverado & Heavy Duty w/ CMS Track (*2)	6' 6"	SB	TR2054	TR5068
07-08	Silverado & Heavy Duty w/ CMS Track (*2)	8'	LB	TR2055	TR5069

CMS = Cargo Management System

<b>DODGE</b>					
87-08	Dakota****	6' 5"	SB	TR2006	TR5029
00-08	Dakota Quad Cab* (****)	5' 3"	XSB	TR2006	TR5006
94-01	Ram	6' 5"	SB	TR2007	TR5077
94-01	Ram	8' 1"	LB	TR2008	TR5090
2002	Ram 1500	6' 2"	SB	TR2022	TR5033
2002	Ram 1500	8'	LB	TR2023	TR5036
2002	Ram 2500/3500	6' 5"	SB	TR2007	TR5077
2002	Ram 2500/3500	8' 1"	LB	TR2008	TR5090
03-08	Ram (incl. Mega Cab)	6' 2"	SB	TR2022	TR5033
03-08	Ram	8'	LB	TR2023	TR5036

<b>FORD</b>					
93-05	Ranger Flareside/Splash**	6'	SB	TR2009	TR5008
82-08	Ranger/Ranger STX	6'	SB	TR2010	TR5008
82-08	Ranger	7'	LB	TR2011	TR5009
73-96	F-Series	6' 8"	SB	TR2013	TR5010
66-96	F-Series	8'	LB	TR2012	TR5090
97-03	F-Series Light Duty & 2004 Heritage	6' 6"	SB	TR2003	TR5003
97-03	F-Series Light Duty & 2004 Heritage	8'	LB	TR2004	TR5004
04-08	F-Series LightDuty	6' 5"	SB	TR2029	TR5003
04-08	F-Series LightDuty	8'	LB	TR2030	TR5042
00-03	Super Crew*	5' 6"	XSB	TR2020	TR5030
04-08	Super Crew* / SuperCab	5' 6"	XSB	TR2028	TR5043
97-03	Flareside & 2004 Heritage FS	6' 5"	SB	TR2019	TR5031
04-08	F150 Flareside	6' 6"	SB	TR2031	TR5047
2008	F-Series Super Duty	6' 9"	SB	TR2069	TR5085
2008	F-Series Super Duty	8' 1"	LB	TR2070	TR5084
99-07	F-Series Super Duty	6' 9"	SB	TR2014	TR5010
99-07	F-Series Super Duty	8' 1"	LB	TR2015	TR5007
00-05	Sport Trac*	4' 3"	XSB	TR2024	TR5032

YEAR	MODEL	BED LENGTH	BOX	CANISTER PART #	RAIL PART #
<b>HONDA</b>					
06-08	Ridgeline	5'	SB	TR2060	TR5082

<b>ISUZU</b>					
88-97	Pup	6' 1"	SB	TR2006	TR5001
88-97	King Cab	5' 11"	SB	TR2006	TR5008
97-00	Hombre	6' 1"	SB	TR2001	TR5001
05-08	I-350 Crew Cab	5'	XSB	TR2034	TR5053
05-08	I-280 Ext. Cab	6' 5"	SB	TR2006	TR5046

<b>MAZDA</b>					
94-08	B-Series	6'	SB	TR2010	TR5008
94-08	B-Series	7'	LB	TR2011	TR5009

<b>MITSUBISHI</b>					
06-08	Raider	5' 3"	SB	TR2039	TR5058

<b>NISSAN</b>					
85-97	Truck	6' 1"	SB	TR2010	TR5001
85-97	Truck	7' 4"	LB	TR2011	TR5012
98-04	Frontier Reg Cab*	6' 4"	SB	TR2011	TR5037
98-04	Frontier King Cab	6'	SB	TR2010	TR5013
98-04	Frontier Crew Cab (*1)	5'	XSB	TR2033	TR5052
02-04	Frontier Crew Cab*	6' 2"	LB	TR2010	TR5013
05-08	Frontier King Cab*	6'	SB	TR2038	TR5057
05-08	Frontier Crew Cab (*2)	4' 10"	XSB	TR2057	TR5080
04-08	Titan King Cab (*2)	6' 7"	SB	TR2067	TR5093
04-08	Titan Crew Cab (*2)	5' 7"	XSB	TR2068	TR5094
04-08	Titan King Cab (*2)	8' 2"	LB	TR2066	TR5090
04-08	Titan Crew Cab (*2)	7' 3"	MB	TR2065	TR5091

<b>TOYOTA</b>					
95-04	Tacoma	6' 1"	SB	TR2006	TR5013
05-08	Tacoma Standard & Access Cabs (*3)	6' 2"	SB	TR2035	TR5054
05-08	Tacoma Double Cab (*1) (*2)	5' 1"	XSB	TR2036	TR5055
05-08	Tacoma Double Cab (*3)	6' 2"	LB	TR2035	TR5054
02-04	Tacoma Stepside	6' 1"	SS	TR2026	TR5013
93-98	T-100 Ext Cab	6' 3"	SB	TR2017	TR5014
93-98	T-100	8' 1"	LB	TR2018	TR5090
99-06	Tundra	6' 2"	SB	TR2017	TR5014
01-06	Tundra	8'	LB	TR2018	TR5004
04-06	Tundra Double Cab	6' 2"	SB	TR2017	TR5048
07-08	Tundra Regular & Double Cab (*2)	6' 5"	SB	TR2051	TR5073
07-08	Tundra Regular & Double Cab (*2)	8'	LB	TR2052	TR5074
07-08	Tundra CrewMax (*2)	5' 5"	XSB	TR2053	TR5079
03-06	Tundra StepSide	6' 2"	SB	TR2027	TR5038

\* Tonneau cover impedes operation of OE Bed Extender option.

\*\* 88-06 Chevy Stepside and 93-05 Ranger Flareside requires drilling holes to mount Rails.

\*\*\* 67-87 Chevy C/K Fleetside requires additional Rail Shims; order part # TRPT1114-5

\*\*\*\* 08 Dodge Dakota requires removal of optional cargo management tie down bars.

(\*1) Raised Top Cover on the canister due to truck bed size.

(\*2) Will impede the use of the optional factory cargo management system

(\*3) Will require the removal of the front tie down hooks

^ Excludes composite box.